

Hinweise zum Umgang mit Rauchmeldern

Um einen störungsfreien Betrieb der Geräte zu ermöglichen, sollten Sie folgendes beachten:

- Zigarettenrauch löst keinen Alarm aus, sofern der Rauch nicht vorsätzlich und direkt in den Rauchmelder gelangt.
- Die Betriebsbereitschaft der Rauchmelder wird durch jährliche Wartungen abgesichert.
- Bitte prüfen Sie bei einem Alarm des Rauchmelders, ob wirklich ein Brandherd existiert! Bei einem Brand folgen Sie bitte umgehend den Anweisungen der Brandschutzordnung!
- Wenn die Alarmbereitschaft des Gerätes gefährdet ist, ertönt regelmäßig ein kurzer Hinweiston (Help-Signal). In diesem Fall informieren Sie bitte umgehend Ihren Hausmeister.
- Die Rauchmelder sind nicht Ihr Eigentum. Eine missbräuchliche Behandlung der Geräte und daraus entstehende Service-Kosten können Ihnen in Rechnung gestellt werden.

Bitte beachten Sie, dass folgende Umgebungseinflüsse zum Störalarm führen können:

- starke Koch-, Brat-, Wasser- und Branddämpfe/ Rauchentwicklung
- große Temperaturschwankungen (starke Wärme/ Hitzeentwicklung)
- Raum-, Duft- und Insektenspray
- Blüten-, Bau-, Schleif-, und Feinstaub

Um einen Störalarm zu vermeiden, sollte das Gerät vor solchen Umgebungseinflüssen geschützt werden. Auch eine vorsichtige, regelmäßige Reinigung kann Abhilfe schaffen.



Beim Kochen in der Nähe des Rauch- u. Wärmemelders ist auf eine gute Belüftung der Räume zu achten.

Ein Störalarm ist durch sanften Druck der Stopp-Taste und durch gutes Belüften der Räume abzustellen.

Bitte achten Sie unbedingt darauf, dass die Lufteinlässe am umlaufenden Rand der Rauchmelder niemals abgedeckt oder durch Staub, Schmutz oder Klebeband etc. beeinträchtigt werden!

Achtung:

Die Rauchmelder unterstützen dabei, Brände frühzeitig zu bemerken, können jedoch weder ein Feuer löschen, noch die Entstehung eines Brandes verhindern und auch nicht die Feuerwehr alarmieren.

Die Rauchmelder geben, wenn Gefahr durch Brandgase und/ oder Brandrauch besteht, einen lauten Alarmton ab, der Sie auf die Gefahr aufmerksam macht.

Die üblichen Vorsichtsregeln im Umgang mit Feuer, brennbaren Materialien und technischen Geräten sind stets zu beachten!

Studierendenwerk West:Brandenburg

Handling instructions for smoke detectors

To enable trouble-free operation of the devices, you should note the following:

- Cigarette smoke does not trigger an alarm unless the smoke intentionally and directly enters the smoke detector.
- The operational readiness the smoke detector is secured through annual maintenance.
- If the smoke detector alarm is activated, please check whether there really is a fire.
- In the event of a fire, please follow the instructions in the fire protection regulations immediately!
- If there is danger that the alarm is not operational, the device emits a shot tone at regular intervals (help signal). If this signal occurs, inform the service department immediately.
- The smoke detectors are not your property. Improper handling of the devices and the resulting service costs can be billed to you.

Please note that the following environmental influences can lead to a false alarm:

- strong fumes of cooking, frying, and fire, water vapors and smoke development
- large temperature fluctuations (strong heat development)
- room spray, fragrance and bug spray
- pollen, construction dust, grinding dust and fine dust

In order to avoid a false alarm from the smoke detector, the device should be protected against such environmental influences. To help prevent false alarms it is also advisable to carefully clean the device with a vacuum cleaner at regular intervals.



When cooking near the smoke detector, ensure that the rooms are well ventilated.

A false alarm can be turned off or prevented by gently pressing the test / stop button and ventilating the rooms well.

Please make sure that the air vents along the circumference of the smoke detector are never covered or impaired by dust, dirt or adhesive tape, etc.!

Attention:

Smoke alarms help to detect fires at an early stage, but cannot extinguish a fire, prevent a fire from starting or alert the fire department.

If there is a risk of fire gases and / or smoke, the smoke detectors emit a loud alarm tone to draw your attention to the danger.

The usual precautionary rules when dealing with fire, flammable materials and technical devices must always be observed!